




















## DLP-S distribution mini-trunking: profiles and accessories

BODIES	SECTION		FINISHING ACCESSORIES						ADAPTORS
	Length 2 m		End cap	Internal angle	External angle	Flat angle	Cover joint	Flat T-junction	For Forix wiring devices
	Wall plugs	With adhesive							
<b>15 x 10</b> 	6 381 00	6 381 09	6 381 05	6 381 01	6 381 02	6 381 03	6 381 06	6 381 04	6 381 07
<b>20 x 12</b> 	6 381 20	6 381 29	6 381 25	6 381 21	6 381 22	6 381 23	6 381 26	6 381 24	6 381 17
<b>24 x 14</b> 	6 381 30	6 381 39	6 381 35	6 381 31	6 381 32	6 381 33	6 381 36	6 381 34	6 381 27
<b>16 x 16</b> 	6 381 10	6 381 19	6 381 15	6 381 11	6 381 12	6 381 13	6 381 16	6 381 14	6 381 37
<b>32 x 16</b> 	6 381 40	6 381 49	6 381 45	6 381 41	6 381 42	6 381 43	6 381 46	6 381 44	6 381 47
<b>40 x 16</b> 	6 381 50	6 381 59	6 381 55	6 381 51	6 381 52	6 381 53	6 381 56	6 381 54	6 381 57
<b>50 x 20</b> 	6 381 60	-	6 381 65	6 381 61	6 381 62	6 381 63	6 381 66	6 381 64	-
	6 381 68	-							
<b>60 x 20</b> 	6 381 70	-	6 381 75	6 381 71	6 381 72	6 381 73	6 381 76	6 381 74	-
<b>40 x 40</b> 	6 381 80	-	6 381 85	6 381 81	6 381 82	6 381 83	6 381 86	6 381 84	-

### DLP-S DISTRIBUTION MINI-TRUNKING AND FORIX WIRING ACCESSORIES: A HIGH QUALITY FINISH

	<p><b>1</b></p> 	<p><b>2</b></p> 
<p>Used vertically or horizontally, the special adaptor hides any cutting flaws on the mini-trunking</p>	<p>When Forix is installed alongside the mini-trunking, the special adaptor needs to be cut</p>	<p>Once the special adaptor is fitted, it will hide the cut on the mini-trunking</p>

### TIME-SAVING AND OPTIMISED INSTALLATION

<p><b>1</b></p> 	<p><b>2</b></p> 	<p><b>3</b></p> 
<p>Remove the protective strip from the adhesive foam on the back of the mini-trunking</p>	<p>Place the mini-trunking in the required position and press it firmly against the wall</p>	<p>The cover fits onto the profile very easily, with a single click</p>